

Cylinder, Piston and Ring Assembly

PART NO.	PART NAME	Qty.
05K21122	KIT – CYLINDER, PISTON AND RING ASSEMBLY	1
14D23913	PISTON-COMPRESSION RATIO 8.00:1	1
74241	RING-PISTON-COMP-5.125 BORE	2
14H29884	RING ASSY - PISTON - OIL REGULATING, EXPANDER TYPE	1
LW-14078	PIN-PISTON	1
72198	PLUG-PISTON PIN	2
71481	RING-OIL SEAL-.09 DIA X 4.84ID	1
70310	SEAL-SHROUD TUBE	2
W-15280	SEAL-SHROUD TUBE	2
06B26669	GASKET - ROCKER BOX COVER (SILICONE)	1
71195	CONTAINER	1
LW-R-0.750-275	O RING	2
77611	GASKET-EXHAUST FLANGE	1
71973	GASKET-2 BOLT FLANGE-1.81 ID	1
SSP-299	TAG: USE OF PISTON PIN PLUGS	1
16G23272-03	CYLINDER HEAD & VALVE ASSEMBLY	0
LW-16290	CYLINDER ASSY	1
78474	BARREL-CYLINDER	1
LW-16289	HEAD-CYLINDER	1
72057	SEAT-VALVE-INTAKE	1
72058	SEAT-VALVE-EXHAUST	1
76943	GUIDE-VALVE-INTAKE	1
16R22126	GUIDE-VALVE-EXHAUST(NI-RESIST)	1
69260	INSERT-SPARK PLUG-18-1.5MM	2
STD-1353	INSERT-#10-24 UNC X .380 LONG	1
31C-12	STUD-.3125-18 X 1.50 LONG	2
25C-8	STUD-.250-20 X 1.00 LONG	1
31-16	STUD-.3125-18 X 2.00 LONG	2
LW-15360	ELBOW-.250-18 X .50 TUBE-45DEG	1
17A23945	VALVE - INTAKE	1
17B23936	VALVE - EXHAUST	1
65441	SEAT-VALVE SPRING-LOWER INTAKE	1
LW-13323	SEAT-VALVE SPRING-LOWER EXHAUST	1
LW-11800	SPRING-VALVE-OUTER (ORANGE)	2
LW-11795	SPRING-VALVE-INNER (ORANGE)	2
LW-10077	SEAT-VALVE SPRING-UPPER INTAKE	1
LW-16475	SEAT-VALVE SPRING-UPPR.EXHAUST	1
60009	KEY - VALVE	2
17C21191	KEY-VALVE-EXHAUST	2

Cylinder, Piston and Ring Assembly (Cont.)

PART NO.	PART NAME	Qty.
LW-15316	CAP-VALVE-EXHAUST	1
16G30140-0101	CYLINDER HEAD & VALVE ASSY (PARALLEL VALVE)	1
16A30140-01	CYLINDER & HEAD ASSY (5.125 BORE) (4.375 STROKE)	1
72057	SEAT-VALVE-INTAKE	1
72058	SEAT-VALVE-EXHAUST	1
76943	GUIDE-VALVE-INTAKE	1
16R22126	GUIDE-VALVE-EXHAUST(NI-RESIST)	1
69260	INSERT-SPARK PLUG-18-1.5MM	2
STD-1353	INSERT-#10-24 UNC X .380 LONG	1
31C-12	STUD-.3125-18 X 1.50 LONG	2
25C-8	STUD-.250-20 X 1.00 LONG	1
31-16	STUD-.3125-18 X 2.00 LONG	2
17A23945	VALVE - INTAKE	1
17B23936	VALVE - EXHAUST	1
LW-11800	SPRING - VALVE - OUTER (ORANGE)	2
17D29055	SPRING - VALVE - AUXILLARY (ORANGE)	2
LW-10077	SEAT-VALVE SPRING-UPPER INTAKE	1
LW-16475	SEAT-VALVE SPRING-UPPR.EXHAUST	1
65441	SEAT-VALVE SPRING-LOWER INTAKE	1
LW-13323	SEAT-VALVE SPRING-LOWER EXHAUST	1
60009	KEY - VALVE	2
17C21191	KEY-VALVE-EXHAUST	2
LW-15316	CAP-VALVE-EXHAUST	1
LW-15360	ELBOW-.250-18 X .50 TUBE-45DEG	1
1102	PLUG-.125 PIPE	2

Part Numbers shown may be Superseded*, and as such should be considered;
 “For Reference Only”!

Please contact Loma-Air in case of doubt

(All Cylinder kits sold contain accurate, current/applicable parts)*